

H03

All-in-One Sleep-Wake Solution
Sunrise Alarm Clock & Sleep Sounds Machine




Thank you for purchasing Odokee Sunrise Alarm Clock Sound Machine. To ensure the best product performance please read this user manual in detail and retain it for future reference.

Questions? Contact Customer Service Center at
odokeeshop@outlook.com


Version 4.0

Odokee

FRONT VIEW



TOP VIEW



1. Press to turn on/pause Bluetooth
2. Hold 2 seconds to turn off Bluetooth when it's connected
3. For streaming music from phone
1. Repeatedly press to set the auto-off timer for sleep sound /nightlight/Bluetooth
2. Hold 2 seconds to turn off timer
3. Press to turn on/off sleep sound
4. Press to decrease sleep sound/Bluetooth volume
5. Press to increase sleep sound/Bluetooth volume
1. Press to start the 9 minutes snooze
2. Press to turn on and change the color of the nightlight
3. Hold 2 seconds to turn off the nightlight
7. Backward
8. Forward
9. Press to turn on/off alarm
10. Press to set the alarm time
11. Press to set the time/switch the regular time and military time


BACK VIEW



12. Scroll to adjust the nightlight brightness
13. Slide to set the alarm sound/alarm volume/sunrise brightness /sunrise duration
14. Slide to select the alarm mode
15. Scroll to adjust the display brightness
16. Power connector
17. Battery compartment


GETTING STARTED

1. Plug the adapter into a standard household outlet, you will see 12:00 AM on the display and the clock is ready to be set.



2. Insert 2 "AAA" batteries(Not Included) on the bottom of the clock to preserve the TIME/ALARM/SUNRISE/SLEEP SOUND/NIGHT LIGHT settings in case of power interruption.

Follow the polarity(+/-) diagram in the battery compartment.



- NOTICE:
1. If the display is "blank" after plugging in, please check whether the **DISPLAY DIMMER** on the left is at the HIGH Position.
 2. Under the battery power, the display will go blank and preset alarm will not go off.
 3. This device is not battery-operated. The battery backup is only used to save your settings to ensure they are not lost during a power outage.

TIME SETTING


The time setting steps are as follows:



1. Press "BT" button once to enter hour setting, the hour digits will flash on the display. Press "BT" or "BT" buttons to advance to the correct hour(hold for rapid setting).



2. Press "BT" button again to confirm and enter minute setting, the minute digits will flash. Press "BT" or "BT" buttons to advance to the correct minute(hold for rapid setting).



3. Press "BT" button a third time to confirm and enter time format setting. "12H" will flash. Press "BT" or "BT" buttons to toggle between 12H and 24H fomats.

4. Press "BT" button a fourth time to confirm and exit the time setting mode.

NOTICE:

1. The clock will automatically exit the time setting mode if no action is taken within 8 seconds.
2. When using the 12-hour time format, the AM icon will appear from 12:00 midnight to 11:59 AM, and the PM icon will appear from 12:00 noon to 11:59 PM.
3. In regular time, AM or PM will be displayed. Otherwise, the clock is in 24-hour (military) time.

BRIGHTNESS CONTROL

There are 0-100% brightness levels for LED Display. Slide the **DISPLAY DIMMER** knob on the left side of the clock to adjust the display brightness (HIGH: 100%, LOW: 0%).

TURNING ALARM ON/OFF

In non-setting mode, each push of "ALARM" button can turn on or disable the alarm.



ALARM TIME SETTING

The alarm time setting steps are as follows:



1. Press "BT" button once to enter alarm hour setting, the hour digits will flash on the display. Press "BT" or "BT" buttons to advance to the correct hour(hold for rapid setting).



2. Press "BT" button again to confirm and enter alarm minute setting, the minute digits will flash. Press "BT" or "BT" buttons to advance to the correct minute(hold for rapid setting).




3. Press "BT" button a third time to confirm and exit the alarm time setting mode.

SUNRISE ALARM SETTING

How the sunrise alarm works


The sunrise alarm gently wakes you up by gradually increasing the light, with its color changing from deep morning red to bright daylight over the last 5 to 60 minutes before the set alarm time, based on the sunrise duration you set.



The light intensity is adjustable, allowing you to customize it to perfectly match your personal light sensitivity, helping improve your morning mood and energy levels.

EXAMPLE:

The light gradually brightens before the alarm time, with the default sunrise duration set to 30 minutes. When the alarm time arrives, the light reaches its preset brightness level, and the alarm sound begins.




Based on 7:00am alarm time.

Customize your sunrise alarm setting on Page 8:




7


1. Slide "BT" on the right side of the clock to **ALARM SOUND** position to enter alarm sound setting. The alarm sound options will flash and the alarm sound will ring. Press "BT" or "BT" to choose one of seven built-in alarm sounds (01=Birds Chirping; 02=Plano; 03=Flute; 04=Forest; 05=Wave; 06=Beep; 07=Buzzer)



2. Slide "BT" on **ALARM VOLUME** position to enter alarm volume setting. The alarm volume options will flash. Press "BT" or "BT" to adjust alarm volume from 01-32 level. The default alarm volume is 16 level.



3. Slide "BT" to **SUNRISE BRIGHTNESS** position to enter sunrise brightness setting. The sunrise brightness options will flash. Press "BT" or "BT" adjust sunrise brightness from 01-30 level. The default sunrise brightness is 15 level.



4. Slide "BT" to **SUNRISE DURATION** position to enter sunrise duration setting. The sunrise duration options will flash. Press "BT" or "BT" to adjust sunrise duration from 05-60 minutes. The default sunrise duration is 30 minutes.



5. Slide "BT" to **LOCK** position to confirm and exit setting mode, display will stop flashing.

Tip:
To exit setup mode at any step, simply slide "BT" to **LOCK** position, and the display will stop flashing.

8

ALARM MODE SETTING



To select the alarm mode, slide "BT" on the left side of the clock to your desired position:

1. Slide to **"LIGHT"** position means wake up light ONLY.
2. Slide to **"SOUND"** position means wake up sound ONLY.
3. Slide to **"SOUND+LIGHT"** position means both.

NOTICE:

The default alarm mode is "SOUND+LIGHT" wake up mode.

SNOOZE/TURN OFF ALARM DAILY

1. When the alarm goes off, press "SNOOZE" button to snooze for a while, the alarm will go off again 9 minutes later.
2. To cancel the snooze at any time or to TURN OFF alarm for the day while it is sounding, press "BT". The alarm will go off again at the same time the next day.
3. If the alarm is not turned off or snoozed, it will automatically stop after 15 minutes.

NOTICE:

1. In the **"LIGHT"** alarm mode, when you start to snooze, the sunrise light will turn off and light up to your preset brightness level after 9 minutes.
2. In the **"SOUND+LIGHT"** alarm mode, when you start to snooze, the sunrise light does not turn off until you turn off the alarm for this day.

9

SLEEP SOUND SETTING

1. Press "BT" to turn on/off sleep sound.
2. When the sleep sound is on, press "BT" or "BT" to choose the sleep sounds (01-25).
3. Press "BT" or "BT" to adjust the volume(01-32 levels adjustable).

Track List			
S01	Lullaby 1	S14	Yoga
S02	Birds Chirping	S15	Meditation
S03	Ocean Wave	S16	White Noise 1
S04	Shush	S17	White Noise 2
S05	Heartbeat	S18	Space White Noise
S06	Rain	S19	Pink Noise
S07	Thunderstorm	S20	Brown Noise
S08	Brook	S21	Blue Noise
S09	Cricket Chirping	S22	Fan 1
S10	Train	S23	Fan 2
S11	Forest	S24	Fan 3
S12	Wind	S25	Fan 4
S13	Lullaby 2		

NIGHT LIGHT SETTING

1. In normal time display mode, press "SNOOZE" to turn on the night light.
2. Press "SNOOZE" repeatedly to choose among 12 different night color options. 12 colors change in the following sequence: sunrise, red, orange, yellow, green, indigo, blue, purple, sunset, loop color, RGB 1, RGB 2.
3. Slide the **NIGHTLIGHT DIMMER** on the right of the clock to adjust night light brightness. (HIGH:100%, LOW:10%)
4. Press and hold "SNOOZE" for 2 seconds (release it) to turn it off.

NOTICE:

The night light will default to the last color you choose when you reopen it.

10

BLUETOOTH CONNECTION SETTING

1. Press "BT" button to turn on/off Bluetooth. When Bluetooth is ON, the "BT" icon will flash on the display.
2. Turn on Bluetooth on your phone and connect to the device "H03". The "BT" icon will stop flashing on the display upon connecting successfully. Press and hold the "BT" for 2 seconds to turn off Bluetooth when it is connected.
3. When music is playing, press "BT" or "BT" to change the music. Press "BT" to pause the music and press again to play.
4. Press "BT" or "BT" to adjust volume with range of 01-32 level.(The default volume is 16 level)




NOTICE:

1. The Bluetooth will automatically turn off if fails to connect to the phone within 5 minutes.
2. If a call comes in, the Bluetooth will stop playing the music.
3. Place your clock and phone no more than 10 meters(33ft) away from each other.

SLEEP TIMER SETTING

- Sleep timer lets you fall asleep with the sleep sound, Bluetooth, or nightlight on for a set duration, then automatically turns these features off.
1. Press the "BT" button repeatedly to select a timer duration: 30, 60, 90, 120, 180, 240 minutes, or OFF. The selected time will be shown on the display.



2. When the sleep timer is set, please wait for 5 seconds to exit the setup. The sleep timer indicator will be seen on the display.
3. Press the "BT" button repeatedly to select "OFF" or press and hold the "BT" button for 2 seconds to turn off sleep timer.
4. When sleep timer is on, press the "BT" button to see the sleep timer remained.

11

NOTICE:

1. When both the nightlight and the sleep sound or Bluetooth are on, the sleep timer can only be set for both features.
2. If the sleep sound, nightlight, or Bluetooth is not turned on, the sleep timer function will be disabled.

INSTRUCTIONAL VIDEO

You can get our H03 product instructional video on your YouTube channel.

Link: <https://youtu.be/pjMlwzIEHTY>



Scan to get instructional video

SPECIFICATIONS

Power Input: DC 5V/2.0A Power: AC, 100-240V (50/60Hz)
Speaker Output: 5 Watt RMS

TROUBLESHOOTING

Q 1. Display doesn't light up?

- A Check if the power connection is loose or not;
- Change another working outlet to try again;
 - Slide the **DISPLAY DIMMER** knob to HIGH position in case the display is too dark to see.
 - Get customer support for help.

Q 2. Display doesn't stop flashing?

- A Check if the "BT" on the right side of the clock is slid to the **LOCK** position.
- Get customer support for help.

12

Q 6. How do I fix Bluetooth connection issues?

- A Confirm that it's not paired with other devices.
- Forget all previous Bluetooth pairings on your device.
 - Unplug the device and remove the battery to reset. Set it up again after the power cycle.
 - Disable and enable Bluetooth on your device.
 - Try connecting the speaker to another device.
 - Contact customer support for help.

WARRANTY & SUPPORT

- We offer a 45 day money-back guarantee and 18-month free replacement.
- Odokee customer support is committed to providing you with best-in-class service. For assistance, please keep the model number and order ID number of this product, then contact us by sending an email to the email address below:
odokeeshop@outlook.com

13