

Odokee

UE268S User Manual

ALL-IN-ONE SOUND MACHINE ALARM CLOCK

18-month Warranty

After-sales mailbox:

support@odokeeshop.com

Please read these instructions carefully before use and retain for future reference.



Instructional Video


You can get our UE268S product instructional video on our YouTube channel.
Link: <https://youtu.be/hNlmLyLkR8E>



Catalog

Instructional Video	2
Front View	4
Back View	5
Top View	6
Bottom View	7
Getting Started	7
Bluetooth Connection Setting	8
Time Setting	9
Switch Time Format(12/24H)	9
Alarm On/Off	10
Alarm Setting	10
Snooze/Turn Off Alarm Daily	12
Sound Machine Setting	12
DST Setting	13
Sleep Timer Setting	14
Brightness Control	15
Wireless Charging	15
USB Charging Port	17
Specifications	18
Troubleshooting	18
Warranty & Support	19


FRONT VIEW




BACK VIEW

Scroll to adjust the sleep sound and bluetooth volume (01-30 level adjustable)


Scroll to adjust the display brightness (0-100%)



TOP VIEW



BOTTOM VIEW



GETTING STARTED


Plug the adapter into a standard household outlet, you will see 12:00 AM on the display and the clock is ready to be set.
Insert 2 "AAA" batteries(Not Included) to preserve the ALARM/ TIME/ WHITE NOISE settings in case of power interruption.

NOTICE:

- 1.If the display is "blank" after plugging in, please check whether the DISPLAY DIMMER on the back is at the HIGH Position.
2. Under the battery power, the display will go blank and preset alarm will not go off.

BLUETOOTH CONNECTION SETTING

1. Press the "BT" to turn on Bluetooth. Press and hold the "BT" for 2 seconds to turn off Bluetooth. When Bluetooth is ON, the "BT" icon will flash on the display.





2. Turn on Bluetooth on your phone and connect with the device "UE268S". The "BT" icon will stop flashing on the display upon connecting successfully.
3. When music is playing, press the "HOUR" or "MIN" to change the music. Press the "BT" to pause the music and press again to play.
4. Slide the **🎵/BT VOLUME** knob at the right side of back of the clock to adjust volume with a range of 01-30 level. The default volume is 30 level(max).


NOTICE:

1. The Bluetooth will automatically turn off if fails to connect to the phone within 2 minutes.
2. If a call comes in, the Bluetooth will stop playing the music.
3. Place your clock and phone no more than 10 meters (33ft) away from each other.

TIME SETTING

1. Press **TIME SET** to enter time setting, the HOUR and MINUTE digits will flash on the display. Press “” to advance to the correct hour, and press “” to advance to the correct minute (hold for rapid setting).

HOUR and MINUTE
Flashes




2. Press **TIME SET** to confirm and exit the Time Setting mode.

NOTICE:

The clock will exit automatically from the Time Setting mode if no action is taken within 15 seconds. (Action refers to pressing the desired button for setup)


SWITCH TIME FORMAT (12/24HR)

Press “” to toggle between 12 and 24 hour mode (the default is 12-hour time format).

NOTICE:



When using the 12-hour time format, the AM icon will be appeared for 12:00 midnight through 11:59am, and the PM icon will be appeared for 12:00 noon through 11:59pm.


ALARM ON/OFF






To switch the alarm on or off, press “”. The alarm icon will appear when the alarm is on.

ALARM SETTING



1. Press **ALARM SET** first time to enter alarm setting, the HOUR and MINUTE digits will flash on the display. Press “” to advance to the correct hour, and press “” to advance to the correct minute (hold for rapid setting).




2. Press **ALARM SET** second time to confirm and enter WAKE UP SOUND setting. The alarm sound options will flash, and the alarm sound will ring. Press “” or “” to choose one of eight built-in alarm sounds (01=Bird Chirping; 02=Piano; 03=Flute; 04=Forest; 05=Wave; 06=Beep; 07=Buzzer; 08=Siren)



"01" Flash and Bird Chirping Ring

3. Press **ALARM SET** third time to confirm and enter ALARM VOLUME setting. Press “” or “” to adjust the alarm volume, 01-30 level adjustable. The default alarm volume is 15 level.




15 Flash and chosen Alarm Sound Ring

4. Press **ALARM SET** fourth time to confirm and exit the Alarm Setting mode.




NOTICE:


The clock will exit automatically from the Alarm Setting mode if no action is taken within 15 seconds. (Action refers to pressing the desired button for setup)

SNOOZE/ TURN OFF ALARM DAILY

1. When the alarm goes off, press **SNOOZE** to snooze for a while, the alarm will go off again 9 minutes later.
2. To cancel the snooze at any time or to **TURN OFF** this day alarm while it is sounding, press “”. The alarm will go off again at the same time the next day.
3. If not stop alarm, it will last 15mins before going silent.


SOUND MACHINE SETTING

1. Short press “” to turn on/off the sound.
2. When sleep sound is on, short press the “” or “” to choose the sleep sounds(01-21).
3. Scroll the **BT VOLUME** knob at the right side of back of the clock to adjust volume with a range of 01-30 level. The default volume is 30 level.



Track List					
1	White Noise 1	9	Fan Sound 4	17	Wind
2	White Noise 2	10	Heart Beat	18	Lullaby 2
3	Space White Noise 3	11	Birds	19	Shhhh Sound
4	Pink Noise	12	Lullaby 1	20	Yoga
5	Brown Noise	13	Waves	21	Meditation
6	Fan Sound 1	14	Rains		
7	Fan Sound 2	15	Thunderstorms		
8	Fan Sound 3	16	Brook		

DST



DST off

(DST default value:off)

DST on


(1 hour forward)

- 1.In Summer time, press the DST ON/OFF button once to turn on DST function, the DST will display on the screen,time will go forward one hour.
- 2.In Winter time, press the DST ON/OFF button once to turn off DST function, the DST will disappear, time will go backward one hour.

SLEEP TIMER SETTING

Sleep timer lets you sleep while listening to sleep sound/bluetooth for the set sleep duration then turns the sleep sound/bluetooth off.

1. When sleep sound/bluetooth on, press repeatedly “⌚” to select the sleep timer ranging from OFF, 30, 60, 90, 120, 180 minutes. The sleep timer will be seen on the display.



Sleep Timer, 180 minutes

2. When the sleep timer is set, please wait for 3 seconds to exit from the setup. The “SLEEP” indicator will be seen on the display.



Sleep Timer ON

3. To turn off the sleep timer, press repeatedly “⌚” to select “OFF” and wait for 3 seconds for it to work.


4. When sleep timer is on, press “⌚” to see the sleep timer remained.

BRIGHTNESS CONTROL

There are 0-100% brightness levels for LED Display. Slide the **DISPLAY DIMMER** knob at the left side of back of the clock to adjust the display brightness (HIGH: 100%, LOW: 0%).


WIRELESS CHARGING

1. For maximum charging efficiency, please place your smartphone centrally on top of the clock as shown.



2. The battery power of your device is shown via your devices display.

3. When the phone is being charged wirelessly, the “⚡” indicator will appear on the display.



NOTICE:

1. Phones that are capable of wireless charging may need to be placed slightly off centre. The built-in wireless receiver may not be centred inside the phone. This varies by brand/model.

2. Compatible with wireless charging enabled devices: iPhone 15/15 Plus/15 Pro /15 Pro Max/14/ 4 Plus/14 Pro/14 Pro Max/14 mini/13/13 Pro/13 Pro Max/13 mini /12/12 Pro/12 Pro Max/12 mini/11/ 11 Pro/11 Pro Max/XS Max/XS/XR/X/8/8 Plus; Samsung Galaxy Note 9/Note8/S8/S8 Plus/S7/S7 Edge/S6 Edge Plus/S9/S10/ S10 Plus/S10E/S20/S21/S22/S23; Google Pixel 7/7Pro/6/5/4/4XL/3/3XL, Nexus 4/5/6/7; LG V50/V40/V35/V30; LG G8/G7/G6; AirPods 3, AirPods Pro, AirPods 2, Galaxy Buds, Galaxy Buds+, Pixel Buds. And other devices with wireless charging function.

- 3.The charging time varies depending on the charging capacity of the battery and its current residual capacity, but wireless charging is generally slower than wired charging.
- 4.The components may heat up during the charging process. They will slowly cool down again after the charging process.
- 5.If charging does not start or slow charging, check the following:
- Remove your smartphone from its case if the thickness of the case exceeds 0.12" (3mm) or if it contains any metal, magnet, pop sockets, grips, stands, or credit cards.
 - Check if your smartphone is placed on top of the clock correctly as shown.
 - If your problem has not been solved by following the above steps, please reach out to us via
- Email: **support@odokeesshop.com**. To expedite your case, please have the following information at hand: your phone's model, and the type of phone case you are using (with a link if possible). Optionally, you may include a video to illustrate the problem you are having.

USB CHARGING PORT

- 1.Connect an external device via a USB cable to the USB charging port on back of the clock to charge the device.
- 2.The battery power of your device is shown via your devices display.

NOTICE:

- 1.There may be some radio interference while charging.
- 2.Please charge your device using only one charging method at any one time.
- 3.Please do not charge the same device using the wireless charging function and USB charging port at the same time.

SPECIFICATIONS

Power Input: DC, 9V/2.5A
USB Output: 5V/1A

Power: AC, 100-240V (50/60Hz)
Speaker Output: 2x5 Watt RMS

TROUBLESHOOTING

1. How Do I Fix Bluetooth Connection Issues?

- Confirm it's not paired with other devices.
- Forget all Bluetooth pairing records on your device.
- Unplug and remove the battery to reset, set again after power cycle.
- Disable and enable Bluetooth on your device.
- Try to connect the speaker to another device.


2. Alarm doesn't go off at the set time?

- Check if the alarm is set to AM or PM time;
- Check if the alarm is turn on (alarm icon display on the screen)


3. Display doesn't light up?

- Check if the power connection is loosed or not;
- Change another working outlet to try again;
- Slide the DISPLAY DIMMER knob to HIGH position in case the display is too dark to see.

4. How to turn off alarm daily?

When the alarm goes off, pressing the “” will turn the alarm off until the next scheduled time.

5. How to turn off the alarm completely?

In the normal time display, you can turn the alarm off completely by single pressing the “”. The alarm icon will be disappear when the alarm is disabled.

WARRANTY & SUPPORT

- We offer a 45 day money-back guarantee and 18-month free replacement.
- Odokee customer support is committed to providing you with best-in-class service. For assistance, please keep the model number and order ID number of this product, then contact us by sending email, email address as below:

support@odokeeshop.com

**Visit www.odokee.net for
18-month Warranty**

- ★ Get your 18-month warranty.
- ★ Get products authenticity verified.
- ★ Get limited-time discounts (if any).
- ★ Get your thoughts shared. Every voice matters.
- ★ Get a copy of the user manual for future reference.

Odokee
CUSTOMER SUPPORT
support@odokeeshop.com

